













# NovoTouch

## Quick Start Guide


(For EK653i / EK753i / EK863i)

### Package Contents

		
Display	Wi-Fi USB Module (with Antennas)	Remote Control
		
Power Cable	Wall Mount	HDMI Cable


		
USB Cable	Audio Cable	Stylus x 2
		
VGA Cable	Batteries	Quick Start Guide

### Display Overview (Front)



- 1 Magnetic Stylus Holders
- 2 Power Button and Status Indicator LED
- 3 IR Sensor (for Remote Control)
- 4 USB 2.0 Port x 2

### Display Overview (Rear)



- 1 Handles
- 2 Wall Mount Screw Holes
- 3 120-Pin OPS Slot (NovoConnect Module)
- 4 Power Switch
- 5 Power Socket
- 6 Speakers
- 7 Wi-Fi Module Slot
- 8 80-Pin Standard Intel OPS Slot



#### Vivitek America

46101 Fremont Blvd, Fremont, CA 94538  
U.S.A.  
T: +1-510-668-5100  
F: +1-510-668-0680

#### Vivitek Asia

7F, No. 186, Ruey Kuang Road, Neihu, Taipei 11491,  
Taiwan R.O.C.  
T: +886-2-8797-2088  
F: +886-2-6600-2358

#### Vivitek Europe


Zandsteen 15, 2132 MZ Hoofddorp  
The Netherlands  
T: +31-20-800-3960  
F: +31-20-655-0999

www.vivitekc.com


A brand of 

## Ports and Connectors

Right







Bottom




- |   |   |                   |
|---|---|-------------------|
| 1 HDMI Out Port                                   | 6 HDMI In Port 3                                  | 11 RS-232 In Port |
| 2 USB 3.0 Ports x 3                               | 7 Touch (USB-B) Port 2 (for use with HDMI 2 Only) | 12 Audio Out Jack |
| 3 Touch (USB-B) Port 1 (for use with HDMI 1 Only) | 8 VGA In Port                                     | 13 LAN Port       |
| 4 HDMI In Port 1                                  | 9 Audio In Jack                                   | 14 USB 2.0 Port   |
| 5 HDMI In Port 2                                  | 10 SPDIF Port                                     |                   |

## Connections



## Remote Control




- |                                       |                            |
|---------------------------------------|----------------------------|
| 1 Power                               | 14 F1 - F12*               |
| 2 Start*                              | 15 Mute                    |
| 3 Spacebar*                           | 16 Close Window*           |
| 4 Numeric Keypad                      | 17 Switch Window*          |
| 5 Display Information Button          | 18 Function Button         |
| 6 Input Source                        | 19 Home Screen             |
| 7 Lock/Unlock Buttons and Touchscreen | 20 Settings Menu           |
| 8 Blank Screen                        | 21 Freeze Screen           |
| 9 Lock/Unlock                         | 22 Backspace               |
| 10 Navigation Buttons                 | 23 Lock/Unlock Touchscreen |
| 11 Quick Draw                         | 24 Back                    |
| 12 Page Up/Down*                      | 25 Volume +/-              |
| 13 Function Buttons                   |                            |


\*Only functional when the optional Windows OPS unit is installed into the display.

## Getting Started


Remove the Wi-Fi module cover, install the Wi-Fi module, and then install the antennas onto the module.



Plug the power cable into the display and a power source, turn the power switch on, and then press the power button.



## Home Screen



- |                                   |                              |                   |
|-----------------------------------|------------------------------|-------------------|
| 1 NovoConnect App                 | 5 Tools Menu                 | 9 Input Sources   |
| 2 Web Browser                     | 6 All Apps                   | 10 Network Status |
| 3 Finder File Management App      | 7 Note Drawing App           |                   |
| 4 NT Minutes Screen Recording App | 8 NovoDS Digital Signage App |                   |