



# QUICK START GUIDE

GUIDE DE DÉMARRAGE RAPIDE  
 GUÍA DE INICIO RÁPIDO  
 GUIA DE INICIO RÁPIDO  
 快速入门指南  
 クイックスタートガイド  
 간편 시작 안내서  
 دليل التشغيل السريع  
 GUIDE DE MISE EN ROUTE  
 GUÍA DE INICIO RÁPIDO  
 GUIA DE CONSULTA RÁPIDA  
 Schnellstartanleitung  
 КРАТКОЕ РУКОВОДСТВО  
 INSTRUKCJA SZYBKIEGO URUCHOMIENIA  
 GUIDA RAPIDA  
 快速使用手册  
 คู่มือเริ่มต้นใช้งานอย่างย่อ




Use screwdriver to release battery cover and remove plastic battery projector




## AC

Initially, plug Qumi in to an AC outlet.





## HDMI/USB/microSD



Connect or plug in your source(s)


Slide lens protector to the right to expose the lens




Kick stand

Image size is dependent on how far back from the screen the Qumi is placed


27" diagonal      100" diagonal




Minimum and maximum image sizes



Focus using buttons on Remote



## Screen- Mirroring 1



Consult the full User Manual for detailed instructions.

## Screen- Mirroring 2



Scan QR code from mobile device.

## Important Notice

Qumi Q3 Plus full User Manual is available on:

- The projector's internal memory:  
Home page → Apps → File Browser → Local Disk → QumiQ3Plus-UM
- Browse to the Vivitek USA web site at:  
[www.vivitekusa.com/category/Qumi/](http://www.vivitekusa.com/category/Qumi/)

